

## **PETER'S PERFECT WATER RECIPE** for the Bromine System

Remove the filter(s), and fill the spa through the filter hole to the fill line on the weir gate, or approximately two or three inches above the filter(s).

Turn on the power at the service disconnect, or at the main breaker. There will be a short delay and then the tub will come on. Turn on the jets and verify that there is sufficient water flow.

- Set the temperature.
- Set the filter cycle to 12 hours of filtration for every 24 hours period.
- Add two, 2 oz. pouches of **Sodium Bromide**, and one 16 oz. bottle of **Metal Gone** to new water.
- Fill the **Floating Brominator**  $\frac{3}{4}$  full with **Bromine Tablets**, and open the orifice to only one or two holes.
- Test the water with a test strip, and adjust pH. (Using **Spa Up**, or **Spa Down**.)
- Adjust. Total Alkalinity. (Using **Alkalinity Increaser** or **Spa Down**.)
- Adjust Total Hardness. (Using **Calcium Booster**.)

### **WEEKLY:**

- Monday**      Test water and adjust pH, Alkalinity, and Bromine level.  
(Using **Spa Up**, or **Spa Down** and **Alkalinity Increaser**.)  
Add one ounce of **Bright and Clear**.  
Add one ounce of **Spa Perfect**.
- Wednesday**      Add one ounce of **Spa Defender**.
- Friday**            Add two ounces of **Renew Shock**.

**MONTHLY:**    Soak filters in **Filter Cleaner** for at least three hours, or overnight.

#### **SANITIZING**

Bromine  
Renew Shock

#### **MAINTENANCE**

Bright and Clear  
Spa Defender  
Spa Perfect  
Cartridge Filter Cleaner

#### **ADJUSTING**

Spa Up  
Spa Down  
Alkalinity Increaser  
Calcium Booster  
Test Strips